

Walton Berkswich Village Hall Sound Controls


1 Sound controls are inside cupboard #9 located on the main stage. Please request the key from waltonberkswichvillagehall1@gmail.com prior to your event.



2 Plug in amplifier and switch on. Please unplug when finished



3 Switch on amplifier and adjust volume for required input.



4 Plug in required input from below selection.

Apple phone



Android Phone



3.5mm Jack



Hand Mic



Head Mic

